

Ego r c v k d r g ' D t c p f u

 Frequency	Frequency	Model	Pictures
ADYX	433.920	ALIZE EM2C, ALIZE EM4C	
AETERNA	433.920	TX433 1,2,4 buttons	
ALLMATIC	433.920	AEMX1, AEMX2, AEMX4	
ALLMATIC	433.920	EUROPE AUTO ARMY1, ARMY2, ARMY4	
ALLMATIC	433.920	MX1, MX2, MX4	
ALLTRONIK	433.920	S429_1, S429_2, S429_4, S429_M Be sure that your remote operates at 433.92MHz!	
ALLTRONIK	433.920	S425	
ANSONIC	433.920	SA 434-1E, SA434-2E, SA434-3E, SA434-4E	
ANSONIC	433.920	SA 434-1MINI, SA434-2MINI, SA 434-2Midi	
APERTO	433.920	CPS1, CPS2, CPS4	
AVIDSEN	433.920	100601 micromark MM23164	
AVIDSEN	433.920	104505	

AVIDSEN	433.920	100951, 100955, 100550, 100400	
B&D BnD BD	433.920	062170/4333EBD, 062171, 4333A	
B&D BnD BD	433.920	62162	
B&D BnD BD	433.920	PTX4 059120 / 059116	
BANDY	433.920		
BELFOX	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version	
BELFOX	433.920	DHS 433,92 (7733), dip switch version	
BENINCA	433.920	LOT1W, LOT2W, LOT4W	
BENINCA	433.920	LOT2WMS	
BENINCA	433.920	T2WK, T4WK	
BENINCA	433.920	LOTX1W, LOTX2W, LOTX4W	
BENINCA	433.920	TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK	
BESIDE	433.920	BEZAP	
BESIDE	433.920	HIT	
BFT	433.920	TE01, TE02 (TE01, TE02)	
BFT	433.920	TE04 (TE04)	

BREDA	433.920	Breda TOP432SA	Like CAME TOP432SA, blue
CAME	433.920	Came TWIN2, TWIN4	
CAME	433.920	CAME TOP-432EV, TOP-434EV	
CARDIN	433.920	S476 TX2, S476TX4	
CASALI GENIUS	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433	
CASIT	433.920	ERTS92B, ERTS92T	
CASIT	433.920	ERTS20DB, ERTS20DQ	
CASIT	433.920	ERTS476D, ERTS476Q	
CASIT	433.920	TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T	
CELINSA	433.920	S10 1, S10 2, SAW1,	
CENTURION	433.920	CLASSIC, SMART, SMART2	
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN	433.920	4330E, 4332E, 4333E	
CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN	433.920	4335E	
CPS	433.920	TCP3, CPS, Jolly 4	
CPS	433.920	CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV	
DASPI	433.920	Daspi Happy2 433, Daspi Pops2	

DASPI	433.920	Daspi Zero2, Zero2CLO, Zero4CLO	
DEA	433.920	433 1, 433 2, 433 4, Gold S1, Gold S2 Dea Gold 238 S1, Dea Gold 238 S2, Dea Gold 239 S4	
DEA	433.920	Punto S2	
DEA	433.920	Dea MIO TD2, MIO TD4	
DELMA	433.920	Mizard 433 1, Mizard 433 2	
DELMA	433.920	King 433 2	
DELMA	433.920	Style Copy 2CH (this is a code duplicator)	
DICKERT	433.920	MAHS433 01, MAHS433 04 Note: we can NOT guarantee that it can be duplicated, because it depends by the receiver.	
DICKERT	433.920	S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 Note: only RED buttons model can be duplicated!	
DICKERT	433.920	S5-433-A2L00, S5U-433-A2L00 Note: only RED buttons model can be duplicated!	
DITEC	433.920	GOL4C	
DOITRAND	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE	
FDOITRAND	433.920	TS2DE, TS4DE	
DOORHAN	433.920		
DOORMATIC	433.920	SAW	

DUCATI ALLDUCKS	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3	
DUCATI ALLDUCKS	433.920	TPR10-A, TPR20-A RONDY TPR10_A, RONDY TPR20_A	
DUCATI ALLDUCKS	433.920	TE2	
DUCATI ALLDUCKS	433.920	HC6203, 6203: only blue with transparent buttons, and transparent with transparent buttons	
ELBE	433.920	501, 502, 504	
ELBE	433.920	502a, 504a	
ELBE	433.920	502, 504	
ELCA	433.920	IRIS, IRIS 9CH. Model 433D only! Both colors red and blue	
ELCA	433.920	ASTER2	
ELCA	433.920	Aster 1000, Aster1001. Model 433D only! Colors: black, blue, light grey	
ELCA	433.920	GEMINI 9CH	
ELCA	433.920	VIRGO	
ELVOX	433.920	Elvox ET	
ELVOX	433.920	Elvox ET03, ET04	
ERONE	433.920	SETDS39433E2, SETDS39433E4	
EUROPE AUTOMATISMES	433.920	ARMY1, ARMY2, ARMY4	

EUROPE AUTOMATISMES	433.920	S1, S2, S3	
FAAC	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS TM1 433DS DPH, TM2 433DS DPH, TM3 433DS DPH	
FAAC	433.920	TML2 433 SLR, TML4 433 SLR, TML2-433-SLR, TML4- 433-SLR, TML2 433 ESL, TML4 433 ESL	
FAAC	433.920	TML2 433 SLP, TML4 433 SLP, TML2-433-SLP, TML4- 433-SLP	
FADINI BPT	433.920	433 2M, Astro43_2m	
FADINI BPT	433.920	Astro433-2, Astro433-4, Astro43-2, Astro43- 4	
FERPORT	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr	
FUNKMODUL ELSECO	433.920	T433A2K1, T433A2K2	
FUNKMODUL ELSECO	433.920	T433A2K4, T433A2K4n	
GIBIDI	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4	
GRIFFON	433.92	Griffon 433 MHz dip switch remotes and duplicating remotes	
GULLIVER	433.920	MDW 2E	
HAUSS	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4	
HORMANN HOERMANN	433.920	HSM2, HSM4, yellow buttons Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!	
HRC	433.920		

JAY	433.920	UBEI x1 SL1	
JAY	433.920	UBET 11, UBET 21, UBET 31, UBET 41, UBET 61Ã ,	
KEY AUTOMATION	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N	
KEY AUTOMATION	433.920	900TXB-44, 900TXG-44	
KEY AUTOMATION	433.920	900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN	
KEY AUTOMATION	433.920	900TXK-42, 900TXW-42,900TXK-44, 900TXW-44	
KING	433.920	<u>Note: receiver should be setup with rolling code feature disabled</u>	
LABEL IUPPITER	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E	
LABEL IUPPITER	433.920	MDW/1E, MDW/2E	
LEB	433.920	TMW	
LEB	433.920	TSAW2N, TSAW4N	
LEB	433.920	TCP3Ã, (this is a code duplicator)	
LEB	433.920	<u>TRK4 Note: receiver should be configured to disable rolling check.</u>	
LEB	433.920	TPW4	
LINCE	433.920	LR 2035	
MA SYSTEM	433.920	MA TX1, MA TX2, MA TX3	
MARANTEC	433.920	D101	






MARANTEC	433.920	D12	
MARANTEC	433.920	Digital 302, D302	
MARANTEC	433.920	Digital 304, D304	
MCZ	433.920	Aster	
MEIÄŦÄ,NER MEISSNER	433.920	LW433-1, LW433-2, LW433-4	
MEIÄŦÄ,NER MEISSNER	433.920	Pocket 3750 1, 2, 4	
MONSEIGNEUR	433.920	ARC2, ARC4	
MONSEIGNEUR	433.920	TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433	
MOTORLINE STATEUROP	433.920	MX1, MX2, MX3, MX6 MX11, MX12, MX13	 
MOTOSTAR	433.920	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534	
NICE	433.920	VERY VE	
NOLOGO	433.920	ECO DIP	
OG	433.920	OG62, OG64	 
O&O OeO, O and O	433.920	OeO T-COM DS 4-2, O&O T-COM DS 4- 4	
OPENOUT	433.920	TMQ 433 2, TMQ 433 4	
PIAZZETTA	433.920	4 buttons for wood/pellet heater	

PORTAMATIC	433.920	MPH01, MPH02	
POWERFIX Profi (Lidl)	433.920	RCB-A 3600R	
PRATEL	433.920	MPSTF2E, MPSTF4E	
PROEM	433.920	ER2C4ACM, ER4C4ACM	
PROGET	433.920	ETY_433N2, ETY 433N4	
PROGET	433.920	EMI433-N2	
PROTECO	433.920	TX433	
PROTECO	433.920	EUROMATIC	
PROTECO	433.920	HIT	
QUASAR	433.920	433 TANGO BLEU	
QUICK	433.92	Model: 302	
ROGER	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R	
ROGER	433.920	H80/TX22	
ROGER	433.920	G80/TX32, G80/TX34, G80/TX32R, G80/TX34R	
SEA	433.920		
SEA	433.920	SMART433_TX2_DIP, SMART433_TX3_DIP SMART433_TX2_COPY, SMART433_TX3_COPY Smart2 Dip Switch, Smart3 Dip Switch	
SEAV	433.920	TXS1, TXS2, TXS3, TXS4	

SEAV	433.920	Behappy S1, Behappy S2, Behappy S3	
SEAV	433.920	Be Easy TX, Be Easy Murale2	
SEAV	433.920	BeSmart S2, BeSmart S4	
SEAV	433.920	BeFree S1	
SECURVERA	433.920	SV R2C	
SECURVERA	433.920	SV R2C	
SECURVERA	433.920	SV R4C	
SECURVERA	433.920	SV R6C	
SENDER	433.920		
SENTRY MARTIN ELECTRONICS	433.920	SENTRY binary	
SERAI	433.920	OG/52, OG/54, OG/82, OG/84	
SERAI	433.920	OG/28, OG/48, OG/62, OG/64	
SERAI	433.920	OG/02, OG/04	
SICE	433.920	TX4 CLACK Bigfoot	
SILVELOX - INTRA	433.920	Silvelox Intra HSM4	
SIMBA	433.920	Simba RC1	
SIMINOR	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS	

SMD	433.920	LW433-1, LW433-2, LW433-4 : AM models only	
SOMFY	433.920	LEB TMW	
STAGNOLI	433.920	ZEUS AZTR	
STARTEC	433.920	TXQ2	
TAU	433.920	250 SLIM, 250K-SLIM, 250K-SLIMC	
TAU	433.920	250TXD2, 250TXD4	
TAU	433.920	250BUG2, 250BUG4	
TAU	433.920	250T-4, 250T-4C	
TECNOMATIC	433.920	TQ433	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1KD, SKX2KD, SKX4KD, SKX6KD	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1DL, SKX2DL, SKX3DL, SKX4DL	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1LC, SKX2LC, SKX3LC, SKX4LC	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1SL, SKX2SL, SKX3SL, SKX4SL	
TEDSEN BERNER GFA Elektromaten	433.920	SKJ	
TEDSEN BERNER GFA Elektromaten	433.920	SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD	

TELCOMA	433.920	TANGO WIN3	
TELCOMA	433.920	TANGO2, TANGO4	
TKC	433.920	TSAW433	
TORAG	433.920	S429 1, S429 2, S429 4	
TORMATIC DORMA	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E	
TORMATIC DORMA	433.920	MAHS, Siebau, Novoferm, Dorma	
TORMATIC DORMA	433.920	MHS, MHS43-1	
TREMA	433.920	TO93TV1, TO93TV2, TO93TV4	
TUBAUTO	433.920	DIGITAL 101 433	
V2	433.920	TCP3	
V2	433.920	TCP3, ARC3	
V2	433.920	TCP3	
V2	433.920	TPR	
V2	433.920	T1SAW/433, T2SAW/433, T4SAW/433	
V2	433.920	TRR1, TRR2, TRR4	
V2	433.920	PMR2, PMR4	

VISIONIC	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP	
VSEG	433.920	CR SLIM	
VISA ELECTRONICS	433.920	Visa Beet 1, Visa Skippy	
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini	 
WAINE-DALTON	433.920	S425	
WECLA CDS	433.920	433, 433_2	